

Table of contents

The role of sample preparation
in gas chromatography

TriPlus RSH robotic sample
handling


Sampling Workflow Editor
software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction
workflows

Micro-SPE clean-up



Guide to automated sample preparation
for GC and GC-MS

TriPlus RSH SMART Workflows

for Environmental, Food & Beverage, and Metabolomics samples

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

The role of sample preparation in gas chromatography

How automation helps modern laboratories

TriPlus RSH robotic sample handling

The tools you need to create a workflow

Sampling Workflow Editor software

Calibration Workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

QuEChERS extract μ SPE clean-up for pesticide analysis



The role of sample preparation in gas chromatography

How automation helps modern laboratories

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

The role of sample preparation in gas chromatography

Gas chromatography is a separation technique widely used in many analytical testing and research laboratories to unravel samples composition or quantify impurities. It is a key analytical tool for many sample types like environmental matrices (water, soil, and air) for the detection of organic pollutants, drugs and pharmaceuticals for toxic impurities, biological samples for clinical studies, chemicals and petrochemicals, food samples for pesticides and other organic contaminants. However, most sample matrices are not suitable for direct injection into a GC system. Samples must be prepared to allow full vaporization before separation and detection at the required concentration limits.

Depending on the complexity of the sample matrix, the isolation of the volatile organic fractions may require extraction, cleanup, derivatization, and in many cases, a concentration step to reach the required sensitivity.

Most of the GC analysis time is taken by sample preparation, often involving several manual handling procedures, which are error-prone and a major source of analytical data variability.

This is why sample preparation represents the most important step prior to GC analysis.



Table of contents

The role of sample preparation in gas chromatography

How automation helps modern laboratories

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows


Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

How automation helps modern laboratories

Sample preparation procedures often represent a tedious and time-consuming part of the analytical workflow for modern laboratories. Also, such procedures often require large quantities of expensive reagents and hazardous solvents that must be disposed.



Increasing the level of automation for sample preparation is the way to relieve laboratories' workload while ensuring, through robotic operation, error-free and highly precise results.

Implementing automated sample preparation workflows for GC involves:

1. Saving labor time through unattended 24/7 operation
2. Saving money through scaling down sample and reagents volumes
3. Increasing confidence in analytical results
4. Reducing human exposure to hazardous chemicals
5. Approaching green chemistry techniques with less waste for more friendly environment procedures
6. Increasing sample throughput, thanks to the capability of overlapping operations while optimizing the overall cycle time.

Thermo Scientific automated sampling solutions combined with advanced and highly sensitive GC and GC-MS instruments are key to supporting modern laboratories to work more efficiently and match their productivity goal.



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

The tools you need to create a workflow

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

TriPlus RSH robotic sample handling

The Thermo Scientific™ TriPlus™ RSH and RSH SMART robotic autosamplers offer a wide range of sample handling tools and accessories, to automate most of the sample preparation procedures.

The Automatic Tool Change (ATC) is the key to automatically swapping between up to six different syringe tools and handling a wide range of volumes and different reagents.

The TriPlus RSH SMART implements technological innovations that further expand automation, performance, and versatility for GC and GC/MS applications.

The SMART technology uses consumables equipped with a unique SMART chip for automatic ID, storage of operational parameters, operational ranges and usage history, enabling full traceability through Thermo Scientific™ Chromeleon™ Chromatography Data System (CDS) tools.



Heating



Vortexing



Dilution



Derivatization



Cooling



Centrifugation



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

[The tools you need to create a workflow](#)

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

The tools you need to create a workflow

The TriPlus RSH and RSH SMART can be equipped with a wide choice of tools and accessories to automatically execute sample handling steps, required to build complex sample preparation workflows.

This eBook is a collection of PrepCycles, developed and validated to execute many sample handling and sample preparation workflows.



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up


Sampling Workflow Editor software

The TriPlus RSH and RSH SMART can be easily programmed by the user to automatically perform the sequence of steps required to produce a customized sample preparation procedure.

The Thermo Scientific™ Sampling Workflow Editor is a very easy and intuitive software for programming your robotic autosampler and create a sequence of sample handling operations for the desired workflow.

This software gives higher flexibility to the operator who can create its own PrepCycle very easily, by listing every single step with a simple drag and drop approach.

To know more about how this software works, look at the Video Tutorial at www.thermofisher.com/Samplingworkfloweditor



Steps Panel: lists the programmable actions according to the configuration

Method Panel: visualizes the steps of the programmed workflow

Modules Panel: displays modules and tools included in the configuration



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

An accurate calibration of the instrument is essential in any chromatographic technique to perform quantitative analyses. A calibration curve is obtained by determining the correlation between the known concentration of target compounds and their analytical response (peak area or height).

This implies the preparation of standard solutions containing the analytes of interest at different concentration levels by diluting with solvent or with blank sample matrix, spanning the concentration range of interest.

Sometimes the procedures for setting up a calibration curve are more complex if additional steps are required, such as the internal standard addition.

The preparation of the calibration standards is a routine time-consuming operation, typically done manually, which requires high accuracy and precision to avoid negative impact on quantitative results.

Automating the calibration method set up is simple and offers several advantages in terms of labor costs and data quality:

- Avoid tedious and time-consuming preparation steps
- Minimize the risk of errors due to incorrect measurement, mislabeling or cross-contamination, improving data confidence.
- Reduce the amounts of reagents, solvents and glassware

Most common calibration methods requiring sample handling

External standard calibration: standard solutions of target compounds at different concentration levels are prepared to create a calibration curve used to quantify those targets in an unknown sample.

Internal standard calibration: a fixed amount of an additional compound (i.e., Internal Standard) is added to each sample and each calibration standard. The concentration of targets is calculated based on the correlation between the peak area ratio and concentration ratio of the targets and the Internal Standard.

Calibration workflows

Standard addition calibration: Incremental amounts of standard at known concentration are added to each unknown sample. The difference of the detected peak areas between the unspiked and spiked unknown sample is used to quantify the target compounds.

The next sections illustrate the available PrepCycles to automate the preparation of calibration standards according to the most common calibration methods.




Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows



Micro-SPE clean-up

In an External Standard calibration method, the absolute analyte response is plotted against the analyte concentration to create the calibration curve.

The Calibration Dilution PrepCycle (Workflow 1) provides the automatic off-line preparation of standard mixtures for external calibration by sequential dilution of a stock solution with a solvent.

This workflow can prepare up to ten calibration levels from undiluted standard to 1:1000 dilution, with the possibility to make each level up to three times.

Schematic principle of External Standard calibration



Example of an External Standard calibration curve. Linear regression is typically used for most detection systems, but quadratic, cubic or mixed models are also possible.

External standard calibration


Workflow 1

Diluting solution addition




Empty vials are placed in fixed positions on the vial tray

Stock solution addition



The solvent volume is added to each vial to obtain the same final volume at different calibration levels

Vortexing



During this step, different volumes of stock solution are added to the vials from a fixed position

During this step, each vial is mixed up

This step is optional

Highlights

- Available as default in Chromeleon and Thermo Scientific™ TraceFinder™ CDS
- This PrepCycle does not include on-line injection. In order to inject the calibration solutions, a separate method must be created



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows


Micro-SPE clean-up

The Internal Standard (IS) is typically a compound with chemical properties similar to target compounds, which is not interfering with sample components in the chromatographic process. More than one IS can be used in case of a sample covering a wide range of volatility and polarity. The calibration plot for each target compound is built reporting the area counts ratio and the concentration ratio with the IS of reference. This is used to correct possible variation of the injected sample amount, since the ratio between the sample components and the IS is not affected.

The Calibration Dilution PrepCycle (Workflow 1) provides the automatic off-line preparation of standard mixtures for internal standard calibration by sequential dilution with solvent of a stock solution, and the addition of a constant aliquot of an internal standard (IS) solution.

Additionally, samples at unknown concentration require the internal standard addition to match the standards preparation. This step is achieved with a dedicated Internal Standard Addition PrepCycle (Workflow 2).

Schematic principle of Internal Standard calibration



Internal standard calibration

Workflow 1

Diluting solution addition



Empty vials are placed in fixed positions on the vial tray

IS addition




The solvent volume is added to each vial to obtain the same final volume at different calibration levels

Stock solution addition



During this step, the same volume of Internal Standard is added to each vial

Vortexing



During this step, each vial is mixed up. This step is optional

Workflow 2

IS addition




During this step, same volume of Internal Standard, is added to each sample vial

Vortexing



During this step, each vial is mixed up. This step is optional



Example of Internal Standard calibration with linear regression

Highlights

- Available as default in Chromeleon and Thermo Scientific TraceFinder CDS
- These PrepCycles do not include on-line injection. In order to inject the calibration solutions, a separate method must be created
- The Internal Standard addition PrepCycle (Workflow 2) can be used for other purposes, such as the addition of surrogates or reagents

Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows



Micro-SPE clean-up

Standard addition calibration

The Standard Addition calibration is used in case sample matrix is not easily reproducible for external calibration purposes. In this case, increasing aliquots of a standard mixture are added to the samples and the increased response of the target compounds is plotted in the calibration curve.


The Standard Addition Quantitation PrepCycle (Workflow 3) automates the addition of increasing aliquots of the standard mixture to the samples and of the compensating solvent to obtain the same final volume.

Schematic principle of Standard Addition calibration



Example of Standard Addition calibration with linear regression. The increased standard aliquots added to the sample sum up to the unknown amount in the sample, which is then extrapolated.

Workflow 3



At the beginning of the procedure, the operator adds a sample aliquot to all vials dedicated to the calibration

Increasing amounts of standard solution are added to the vials containing the sample. Up to six increasing aliquots, from 1 to 100 μL , can be added

Optional step: If required, different solvent amounts are added to compensate for volume differences

During this step, each vial is mixed up. This step is optional

Highlights

- This PrepCycle does not include on-line injection. In order to inject the samples containing the standard additions, a separate method must be created



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

External standard calibration

Internal standard calibration

Standard addition calibration

Instrumental set-up for calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

Automated calibration workflows


Minimum instrument set-up

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools. The calibration dilution configuration requires liquid tools with a 10 μL and a 1000 μL syringe

Tray Holder

Holds up to 60 20 mL/10 mL vials or up to 162 2 mL vials. In the calibration dilution workflow, up to three series of vials can be prepared, each consisting of up to 10 concentrations



Standard Wash Station

Used for syringe washing or solvent and solution storage. In the calibration dilution configuration, this station holds the dilution solvent for 1–3 calibration solutions (positions 1–3) and the stock solution to be diluted (position 4)

Large Wash Station

Used for syringe washing or solvent and solution storage. In the calibration dilution configuration, this station is used exclusively for syringe washing. Positions 1 and 2 are used for washing after internal standard and stock solution addition, respectively

Vortex Mixer

Employed for sample mixing after reagent or standard addition

Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Fits on a standard rail length
- Vortex Mixer optional but recommended
- Bench workstation compatible



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows


Micro-SPE clean-up

Derivatization workflows

Derivatization protocols are a common practice in GC and GCMS for changing the analytes' properties to improve their volatility, get a better separation and enhance the method sensitivity.

Derivatizing agents are reactive compounds capable of coupling to specific compound classes. Following derivatization, a stable new compound is generated bearing different physical-chemical properties.

Examples of common reactions are alkylation (e.g., methylation), formation of aryl derivatives, silylation (e.g., formation of trimethylsilyl derivatives), acylation (e.g., reactions with acyl chlorides or with chloroformates).



Why derivatize?

- To convert non-volatile/thermally unstable compounds into volatile/thermally stable adducts
- To introduce in the molecule a chemical group that significantly increases sensitivity with respect to a certain type of detector
- To increase analyte stability (even though, in some other instances derivatization results in products with limited stability over time)
- To obtain a similar response behavior from all analytes with respect to the detector (e.g., MS).

Automation greatly benefits derivatization workflows

Derivatization procedures are often complex and very time consuming and may involve the use of hazardous chemicals.

Automation provides several advantages:

- Significant labor time saving
- Increased sample throughput with optimized cycle time and 24/7 operations
- Enabled online GC injection after derivatization to prevent possible degradation of unstable adducts, or derivatization in batches for high productivity
- Minimized human exposure to hazardous chemicals
- Improved overall standardization and analytical performance repeatability, since every derivatization reaction may require specific conditions (e.g., agitation, temperature, pH).

Resources

[Guide to Derivatization for GC and GC-MS](#)

[Automated Workflow Solutions Web Page](#)



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Batch derivatization

The Batch Derivatization Workflow performs all the derivatization steps for a batch of up to six samples, with reagent addition, shaking, and incubation, allowing a wide range of customization options.


The sequence of operations can be performed twice for a two-step derivatization protocol. Alternatively, one of the two cycles can be used for internal standard addition.

Derivatization reactions can be achieved in the incubator at a controlled temperature or at ambient temperature.


Samples can be stored in a temperature-controlled tray or drawer (optional).

Once derivatization is completed for the sample batch, a separate sequence must be created for injection into the GC system.

Schematic principle



Workflow



Highlights

- Up to six samples prepared in batch before injection
- Optional second derivatization reagent or IS addition
- Optional second incubator for protocols including two different derivatization temperatures
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats


ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Workflow




Sequential derivatization

The Sequential Derivatization Workflow prepares each sample and injects it sequentially. The workflow includes two steps for the addition/vortexing of a standard mixture, typically an internal standard and a Retention Index standard, and up to two steps for possible addition of two different derivatization reagents.

This workflow permits the optimization of the overall cycle time thanks to overlapping with the GC run time. Minimizing the time between the derivatization process and the injection, it is preferred in the case of labile derivatives.

Schematic principle



Highlights

- Each sample is prepared and injected sequentially
- Steps overlapping for cycle time optimization
- Two different incubation temperatures can be handled
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization workflow on a standard X-Rail


Minimum instrument set-up

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools. It is possible to dispense from 1 μL up to 1000 μL using three different syringes. The 10 μL syringe is mandatory; the 100 μL and the 1000 μL syringes are optional items

Tray Holder

Used to store sample vials, it has a maximum capacity of 162 \times 2mL vials. Alternatively, a Cooled Drawer is recommended for sample storage under controlled temperature (4–40 $^{\circ}\text{C}$)



Vortex Mixer

Employed for sample mixing up to 2000 rpm after reagent or standard addition. Compatible with 0.5, 0.7, 2, 5, 10, or 20 mL vials

Agitator/Incubator

Used for sample incubation after derivatization reagent addition

Standard Wash Station

Used to wash the syringe before/after reagent addition and prior to injection with different solvents for one or more washing cycles. The Large Wash Station and Fast Washing Module are also compatible with this custom cycle

Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Either batch or sequential workflow fits on a regular rail length
- Two incubators possible to handle different reaction temperatures
- Bench workstation compatible for off-line sample derivatization



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization workflow on the extended X-Rail

Extended instrument set-up

Cooled Drawer

Electrical temperature-controlled drawer for well plates, 300 µL fixed insert vials, 2 and 10 mL vials. It allows to store samples at a controlled temperature between 4 and 40 °C, before and after the derivatization

Vortex Mixer

Employed for sample mixing up to 2000 rpm after reagent or standard addition. Compatible with 0.5, 0.7, 2, 5, 10, or 20 mL vials

Large Solvent Station

Up to 3 × 100 mL solvent bottles

Large Wash Station

Optional large wash station for up to 2 × 100 mL solvent bottles and one drain position

Agitator/Incubator

Used for sample incubation after reagent addition. Two incubators can be configured to handle two different derivatization temperatures

Tray Holder


Used to store sample vials with a maximum capacity of 162 × 2 mL vials. Configured in addition to the Cooled Drawer to increase sample capacity

Standard Wash Station

Used for up to four different solvents for a total of 40 mL and 1 × 10 mL wast

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools



Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Flexible configuration with additional tools possible such as the Temperature Controlled Drawer
- Higher sample/solvent capacity for longer unattended sequences
- Bench workstation compatible for off-line sample derivatization



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Dual-step sequential derivatization for metabolomics

The metabolome consists of low molecular weight (< 1500 Da) metabolites found in a biological system. Metabolomics aims to achieve a comprehensive characterization of the metabolome of cells, biofluids, tissues or organisms, known as metabolic profiling, useful for health assessment.

GC-MS is a powerful tool to characterize the metabolic profile and extensively used in metabolomic studies.



Discriminatory analysis (Volcano-plot)


Metabolomics studies typically generate thousands of analytical features, collected over extended periods of time. Standardization is therefore one of the main requirements for the success of a metabolomics study as it improves confidence in data collected over time.

Statistical analysis is used to understand and interpret the data and reveal variables associated with different sample groups.

Low molecular weight compounds contained in biological samples are often non-volatile and unstable at the temperatures normally used in GC analysis.

Compound derivatization is necessary to increase the volatility of metabolites containing polar functional groups, such as carboxylic and amino groups.

A commonly used metabolomics workflow involves a dual-step derivatization consisting of methoximation, followed by silylation.



Methoximation



Silylation

This two-step derivation is preferable with a sequential workflow approach where single samples are prepared and injected sequentially for best integrity of labile TMS-metabolite.




Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows


Micro-SPE clean-up

Sequential derivatization workflow in metabolomics


Dual-step automated workflow



RSD% of Amino Acids Using Online Derivatization



Online vs Manual Derivatization (RSD%)



Resources

[Thermo Scientific Application Note AN10594](#)

[Presentation: Back To the Future](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- The derivatized sample is immediately injected to prevent degradation
- Improved data precision
- 24 samples can be prepared and analyzed in 24 hours
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Sequential derivatization workflow for metabolomics

Instrument set-up

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools. It is possible to dispense from 1 μL up to 1,000 μL using three different syringes. The 10 μL syringe is mandatory, the 100 μL and the 1000 μL syringes are optional items

Agitator/Incubator

Used for sample incubation after derivatization reagent addition

Large Wash Station

Large wash station for up to 2 \times 100 mL solvent bottles and one drain position

Vortex Mixer


Employed for sample mixing up to 2000 rpm after reagent or standard addition. Compatible with 0.5, 0.7, 2, 5, 10, or 20 mL vials

Standard Wash Station

Used to wash the syringe before/after reagent addition and prior to injection with different solvents for one or more washing cycles. Large Wash Station and Fast Washing Module are also compatible with this custom cycle

Tray Holder

Used to store sample vials, it has a maximum capacity of 162 \times 2 mL vials. Alternatively, a Cooled Drawer is recommended for sample storage under controlled temperature (4–40 $^{\circ}\text{C}$)



Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

Highlights

- Fits on standard rail length
- Two incubators are used simultaneously at different derivatization temperature
- Bench workstation compatible for off-line sample derivatization

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization of melamine and its derivatives in dairy products

According to U.S. FDA protocol


Melamine and its derivatives are inexpensive, nitrogen-rich compounds, which can be used as adulterants in food and/or animal feed to increase their market value by increasing their protein content.

Milk and dairy products are particularly prone to such adulteration, which also impacts processed food containing dairy-based ingredients.


Cyanuric acid, ammeline, and ammelide are the by-products which are screened together with melamine in dairy products.

With GC-MS/MS, it is possible to determine the content of the four compounds with excellent sensitivity and specificity. However, the extracted samples must be derivatized before the analysis.


The derivatization procedure can be automated, with online injection into the GC-MS/MS system.




Melamine






Ammeline



Ammelide



Cyanuric acid



SRM results from a milk sample spiked with 12 ppb of each compound



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4



Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization of melamine and its derivatives in dairy products

Automated workflow



Resources

[Poster Note PN10388](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Online injection in the GC-MS/MS system
- Improved data precision
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization of melamine and its derivatives in dairy products


Instrument set-up

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools. It is possible to dispense from 1 μL up to 1,000 μL using three different syringes. The 10 μL syringe is mandatory, the 100 μL and the 1000 μL syringes are optional items

Standard Wash Station

Used to wash the syringe before/after reagent addition and prior to injection with different solvents for one or more of washing cycles. Large Wash Station and Fast Washing Module are also compatible with this custom cycle



Vortex Mixer

Employed for sample mixing after reagent or standard addition

Agitator/Incubator

Used for sample incubation after derivatization reagent addition

Tray Holder

Used to store sample vials, it has a maximum capacity of 162 \times 2 mL vials. Alternatively, a Cooled Drawer is recommended for sample storage under controlled temperature (4–40 $^{\circ}\text{C}$)

Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

Highlights

- Fits on regular rail length
- Online injection to GCMS
- Bench workstation compatible for off-line sample derivatization

Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up


Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization workflow for biodiesel analysis


Free and total glycerol by Methods EN 14105 and ASTM D6584

Biodiesel is a clean burning alternative to fossil fuel, obtained from renewable sources such as vegetable or fat oil. The interest in biodiesel originates from its reduced environmental impact. Biodiesel is commercialized in pure form or in a blend with conventional diesel fuel and it can be used for heating or as engine fuel.



In biodiesel manufacturing, the raw oil is reacted with methanol in the presence of a strong base. The product is a mixture of fatty acid methyl-esters (FAMES) and glycerol, along with unreacted mono-, di-, and triglycerides and methanol.

Regulations set a maximum in the content of glycerin expressed as an aggregate of free and bonded forms.




Mixture of compounds after transesterification of vegetable oil

In standard methods, the sample undergoes derivatization using MSTFA (N-Methyl-N-(trimethylsilyl)trifluoroacetamide), which reacts with the free hydroxy groups.

The resulting adducts are analyzed by GC-FID. The reaction is finally quenched by adding heptane.

Dedicated PrepCycles are available to comply with methods EN 14105 (one IS) or ASTM D6584 (two IS), both with or without the calibration standards preparation.

Automation is greatly beneficial for this procedure which otherwise would require 1–1.5 hours of manual operation, including calibration standards preparation.



Example of chromatogram of biodiesel sample for free and total glycerol determination



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up


Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization of free and total glycerol in biodiesel

Automated workflow

ASTM D6584 and EN 14105 PrepCycles are available also in the version including the calibration standards preparation, with 4 or 5-point calibration according to the method.



Resources

[ASTM D6584-17](#)

[BS EN 14105:2020](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Dedicated PrepCycles for ASTM D6584 or EN 14105 methods, with or without calibration standards preparation
- Internal Standard addition included
- On-line injection is optional. The system can be used as a preparation bench station for off-line sample derivatization
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization of free and total glycerol in biodiesel

Instrument set-up

Automatic Tool Change Station

Supports docking and exchange of up to three liquid tools: the cycle uses a 100 µL syringe to prepare the calibration curve and add the standards and derivatizing agent and a 10 mL syringe to add the 8 mL of heptane needed to quench the reaction. A 10 mL syringe is then used for GC injection.

Large Solvent Station

Used to hold the heptane employed to quench the derivatization reaction

Large Wash Station


Used for generic syringe washing. To avoid cross-contamination, syringe washing steps performed before and after standard addition or MTSEA addition make use of dedicated reservoirs placed on the tray holder

Vortex Mixer

Employed for sample mixing after reagent or standard addition

Tray Holder

Used to store sample and solution vials, in this configuration it is equipped with three VT15 trays, each having a capacity of 15 × 10 mL vials. Tray 1 holds the derivatizing agent internal standard and stock solutions as well as dedicated wash solutions for each of the addition steps. Tray 2 and tray 3 hold samples and calibration solutions



Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

Highlights

- Suitable for both ASTM and EN methods
- Fits on standard rail length
- On-line injection or bench configuration for off-line sample derivatization



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows


Micro-SPE clean-up

Derivatization workflow for fatty acids in food

Fatty acid composition provides critical information as to the quality and trading value of oil seeds and processed oil, as well as nutritional information on fat-containing food. Data on fatty acid composition also need to be reported in the label of conventional foods and dietary supplements.

Oils and fats in foods are composed of four different types of FAs: polyunsaturated, monounsaturated, saturated, and TFAs (Trans).

Since the amount and the composition of fat consumed every day has a major impact on health—especially towards the development of atherosclerosis—fatty acid composition is considered to be an important index of food quality.




Examples of the different types of fatty acids

Fatty acid analysis in food proceeds through fat extraction, followed by derivatization and analysis by GC-FID. The derivatization step aims to convert triglycerides into fatty acid methyl-esters (FAMES).

In case of common fats and oils, FAMES can be directly prepared in a single transesterification step, but in general, such reaction involves two consecutive steps.

A first acid or basic hydrolysis produces free fatty acids (in an acidic solution) or their salts in case of a saponification reaction in a basic solution.

Then, the second step includes the methylation where the free FAs are esterified with methanol, in presence of an acid catalyst like BF₃ (boron trifluoride) or a basic catalyst like NaOH or KOH (sodium or potassium hydroxide).



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up


Fatty acid esterification

Automated workflow according to AOCS-CE 2-66



At the beginning of the procedure, an operator weighs an aliquot of extracted fat sample within a 2 mL vial

Saponification and methylation are carried out sequentially under temperature-controlled conditions



Solvent (heptane or iso-octane) is added

FAME extraction is facilitated by shaking and salting out

The organic phase is transferred into a separate vial where it is ready for injection

Resources

[Webinar: Benefits of Automated Sample Preparation Workflow to Reduce Costs and Increase Lab Efficiency: The Case of FAMEs](#)

[AOCS-CE 2-66 Method](#)

Highlights

- Low exposure to hazardous chemicals
- Increased data precision
- High sample throughput capabilities



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Fatty acid esterification

Instrument set-up according to Method AOCS-CE 2-66



Resources

[Automated Workflows Brochure](#)


[SampleQ Application Note 20210208](#)

[Automated Workflow Solutions Web Page](#)

[SampleQ Web Page](#)

Highlights

- Method tested on customer's sample
- Bench station or on-line serving two GCs



SampleQ[™]

SampleQ is a registered trademark of Interscience.



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Fatty acid esterification


Automated workflow according to Method AOAC 996.01



At the beginning of the procedure, an operator weighs an aliquot of extracted fat sample within a 20 mL vial

Saponification proceeds for 10 minutes at 70 °C

Fatty acid methylation proceeds for three minutes at 70 °C



FAME extraction is facilitated by vortexing and salting out

The organic phase is transferred into a separate vial where it is ready for injection

Resources

[Webinar: Benefits of Automated Sample Preparation Workflow to Reduce Costs and Increase Lab Efficiency: The Case of FAMES](#)

[AOAC 996.01 Method](#)

Highlights

- Increased data precision
- Low exposure to hazardous chemicals
- This PrepCycle can be reproduced with the SWE to modify or create additional steps

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Fatty acid esterification

Instrument set-up according to Method AOAC 996.01



Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

[Automated Workflow Solutions Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Fits in a regular x-rail with 24 samples capacity
- Bench station or on-line injection

Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up


Derivatization workflow for MCPD and GE in edible oils and fats

3-MCPD (3-monochloropropane diol), 2-MCPD (2-monochloropropane diol) and Glycidyl esters (GE) are sources of safety concern for food industry. These compounds are generated as by-products during high-temperature processing or refining of fats and edible oils.


Depending on the type of food they may occur as a free substance, in the form of an ester with fatty acids or in both forms. Because of carcinogenic properties and overall toxicity, both the free form and their esters are highly regulated.

MCPD and GE are analyzed after transesterification and derivatization in order to report total MCPD and GE contents.

A common sample preparation involves the extracted fats to be first submitted to a transesterification step using sodium methoxide, which reacts as well with fatty acid glyceryl esters. The resulting FAMEs are separated by solvent extraction. Glycidol, 3-MCPD and 2-MCPD are then derivatized using Phenyl Boronic Acid (PBA), and finally analyzed by GC-MS/MS.



By-products generated during high-temperature fatty food processing or refining



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Derivatization workflow for MCPD and GE in edible oils and fats

Official methods

The European Union defines fixed limits to the allowed maximum concentration of glycidol, 2- and 3-MCPD and the respective esters in different types of food, Ref: (EU) 2020/1322.

Of the four official AOCS/ISO methods used for the determination of these compounds in food and oils, AOCS Cd29f-21/ISO 18363-4 shows the highest potential for quality control purposes as it allows for high turnaround through easier automation.

This method, recently having been adopted as an official method and permitting the detection of all the three analytes with one sample aliquot, offers the most suitable testing solution for QC laboratories and others where throughput is of the essence.

	AOCS Cd29a-13 / ISO18363-3	AOCS Cd29c-13 / ISO18363-1	AOCS Cd29f-21 / ISO 18363-4
--	-----------------------------------	-----------------------------------	------------------------------------

Reaction Time	16 hours	5,5 min	12 min
Transesterification	Acidic, above Room Temp	Alkaline, Room Temp	Alkaline, below Room Temp
Components	3-MCPDe, 2-MCPDe and GE	3-MCPDe and GE (calculated)	3-MCPDe, 2-MCPDe and GE
Aliquots	1	2	1
Analysis	GC-MS	GC-MS	GC-MS/MS

	AOCS Cd 29a-13	AOCS Cd 29b-13	AOCS Cd29c-13	AOCS Cd29f-21 / ISO18363-4
Sample	100-110 mg	2x 100±0.5 mg	2x 100±0.5 mg	100-120 mg
Pre-treatment	THF /H ⁺ /NaBr, 50°C, 15 min, extr, evap	Diethylether, -25°C	tBME, Room T	Toluene/tBME (ter-butylmethylether)
Trans-esterification	Acidic, H ₂ SO ₄ / MeOH 40°C, 16h	Alkaline, NaOH / MeOH -25°C, 16h	Alkaline, NaOCH ₃ / MeOH RT, 5.5 min	Alkaline, NaOCH ₃ / MeOH 10°C , 12 min
Stop reaction	NaCO ₃ , Evap, RT	H ⁺ /NaBr, -25°C, Evap	H ⁺ /NaCl, RT H ⁺ /NaBr, RT	H ⁺ /NaBr, RT
FAME extraction	Na ₂ SO ₄ + 2x extr n-heptane	2x extr iso-hexane	2x extr iso-hexane	2x extr i-octane
Clean-up	-	3x Et ₂ O/EtAcO, Na ₂ SO ₄	3x Et ₂ O/EtAcO, Na ₂ SO ₄	-
Derivatization	PBA solution	PBA solution	PBA solution	PBA solution
Extraction and re-concentration	2x 1 ml n-heptane, Evap, 400µl n-heptane	Evap, 400µl iso-octane	Evap, 500µl iso-octane	Extr, 600µl i-octane
Detection	MS-SIM	MS-SIM	MS-SIM	MS/MS
Difficulties for automation / manual prep	Evaporation steps, precipitation of salts	Evaporation steps + very low temp	Evaporation steps	Reliable automation

Tables courtesy Zwagerman et. al, Bunge Loders Croklaan

Resources

1. R. Zwagerman, P. Overman, Eur. J. Lipid Sci. Technol. 2019
2. 2- and 3-MCPD Fatty Acid Esters and Glycidol Fatty Acid Esters in Edible Oils and Fats by Acid Transesterification, Official AOCS Methods, AOCS 29a-13, approved 2013.
3. Determination of Bound MCPD- and Bound Glycidol- by Gas Chromatography/ Mass Spectrometry (GC/MS), Official AOCS Methods, AOCS 29b-13, approved 2013.
4. Fatty-acid bound 3-MCPD- and Glycidol- determination in oils and fats by GC/MS (Differential Measurement), Official AOCS methods, AOCS 29c-13, approved 2013



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4

Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

Automated workflow according to modified AOCS Cd 29c-13 or ISO 18363-4




Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows


Micro-SPE clean-up

MCPD and GE transesterification and derivatization

AOCS Cd29f-21/ISO 18363-4



Chromatogram of extra virgin olive oil – spiked where:
3-MCPD at a level of 0.1mg/kg; 2-MCPD at a level of 0.07 mg/kg; GE at a level of 0.1 mg/kg



Close-up of transitions of the three analytes in spiked extra virgin olive oil

Resources

[SampleQ Technical Note SQ20170212](#)

[Webinar: An Automated Workflow Solution for the Determination of MCPDe and GE](#)

[Poster RAFA 2019](#)

[Article: Optimized Analysis of MCPD- and Glycidyl Esters in Edible Oils and Fats Using Fast Alkaline Transesterification](#)

[Analyte Guru Blog](#)

Highlights

- Determination of 2-MCPD is included in this method
- High sensitivity with Triple Quad and AEI source
- No evaporation step is necessary
- Only one injection per sample
- Full automated reporting



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Batch derivatization

Sequential derivatization

Instrument set-up (standard and extended X-Rail)

Dual-step derivatization – metabolomics

Instrument set-up

Melamine and its derivatives – dairy products

Instrument set-up

Free/total glycerol – biodiesel

Methods EN 14105 and ASTM D6584

Instrument set-up

Fatty acid analysis – food

Esterification according to AOCS-CE 2-66

Instrument set-up

Esterification according to AOAC 996.01

Instrument set-up

MCPD and Glycidyl esters – edible oils and fats

ISO 18363-4


Instrument set-up

Liquid/liquid extraction workflows

Micro-SPE clean-up

MCPD and GE transesterification and derivatization

Instrument set-up according to AOCS Cd29f-21/ISO 18363-4



Resources

[Automated Workflows Brochure](#)

www.SampleQ.com

[MCPD Automated Workflow Video](#)

[Zwagerman et al. European Journal of Lipid Science and Technology, 2019, Wiley Online Library](#)

Highlights

- > 100 sample positions
- Batch of 20 samples at once



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Liquid-liquid extraction (LLE) is the most widespread sample preparation technique before chromatography separations. LLE is a method based on the relative solubilities of compounds in two different immiscible liquids, usually water (polar) and an organic solvent (non-polar). During LLE, one or more compounds (or solutes) are transferred from one liquid phase to the other. At the end of the extraction (or partitioning), equilibrium is reached and one of the two phases will be solute-depleted while the other will be solute-enriched.

Liquid-liquid extraction seems relatively simple, but manual operations are time consuming, prone to human error, and involve high solvent consumption.


Automation is greatly beneficial in terms of time and cost savings:

- Highly standardized workflows, including agitation, centrifugation and solvent evaporation
- Scaled down of solvent and sample volumes
- Minimized direct contact of the operator with toxic solvents.


The choice of the right solvent for the extraction is a key parameter, ideally the solvent should display:

- Low reactivity and good dissolving power towards the compound -or the compounds- of interest
- Relatively high volatility, for easy removal after extraction
- Low or no miscibility and high enough difference in density compared to water, for easy phase separation
- Low melting/freezing point and low toxicity and flammability for easy handling and storage.

Liquid-liquid extraction workflows



Commonly used solvents



Water solubility

■ immiscible ■ 0.01 – 10 g/L ■ > 10 g/L



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up





Automated LLE for organic contaminants (SVOC) in water

The presence of organic contaminants in waters and wastewaters represents a serious risk for the environment and human health. Organic contaminants in water belong to a wide variety of chemical structures, such as hydrocarbons, aldehydes, ethers, esters, phenols, organic acids, ketones, amines, amides, nitroaromatics, PCBs (also known as Aroclors), PAHs, phthalate esters, nitrosamines, haloethers, and trihalomethanes.

Sources of these compounds include pesticides and herbicides (containing phosphorus, sulfur, chlorine, or nitrogen), flame retardants, ingredients in cleaning agents and personal care products, solvents, and chemicals used in textile/electronic manufacturing and material manufacturing process additives.

Regulatory bodies worldwide publish extensive lists of contaminants, which are regularly updated with new emerging pollutants. Strict performance limits are required by analytical determination in terms of sensitivity, accuracy, and linearity. This puts an increasing burden on contract testing labs in charge for water analysis.

To date, LLE remains one of the go-to options for organic contaminant extraction from water samples. Laboratories look for options to save on solvent costs and to minimize sample preparation time. However, time-saving and cost-driven measurements should not compromise analytical results, hence the interest for reliable, automated sample preparation, coupled to state-of-the-art GC-MS.



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples


LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Automated LLE for organic contaminants (SVOC) in water

Automated workflow



At the beginning of the procedure, 10 mL of water sample are manually pipetted into a 20 mL headspace vial. Once the vial is placed onto the autosampler tray, the rest of the procedure is carried out automatically

10 μ L of an Internal Standard mixture and 2 mL of solvent (pentane) are sequentially added to the sample by means of two separate liquid tools

A vortexing step (2,000 rpm for 1 minute) promotes analyte partitioning into the organic phase

A five-minute waiting time allows for the organic layer to separate. The organic solvent is sampled and injected

A 200 μ L syringe is used for large volume injection of 50 μ L into a PTV injector

Suitable for...

Matrices

- Ground water
- Surface water
- Sea water
- Drinking water

Analytes

- Pesticides
- Phenoles
- Aromatic amines
- Chlorofenoxycarbonic acids
- PCBs
- PAHs
- Halo acetic acids

Resources

[Webinar: Improvement of Sensitivity, Accuracy and Precision of Quantitative Data Through Automation](#)

[Thermo Scientific Application Note AN10591](#)

[WaterWorld Article](#)

[Analyte Guru Blog](#)

[VERITAS S.p.A. Case Study CS001327](#)

Highlights

- In-vial extraction
- Scale down sample and solvent volumes
- LVI and Triple Quad with AEI ion source for high sensitivity in the low ppt range



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples


LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Automated LLE for organic contaminants (SVOC) in water

Instrument set-up



Resources

[Automated Workflows Brochure](#)

[SampleQ Web Page](#)

[Automated Workflow Solutions Web Page](#)

Highlights

- Fits on regular x-rail
- On-line injection into the GC-MS/MS
- 60 vial positions for 24/7 operations



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples


LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

Automated workflow



- The workflow starts with 8 mL of water sample.
- A micro volume of extraction solvent is added in a dispersive way maintaining an elevated surface exchange, thus dramatically increasing the final concentration of the analytes in the organic phase.
- A centrifugation step is required to separate the organic solvent drop before injection in the GC-MS/MS.
- The enhanced enrichment along with Large Volume Injection (LVI) and Advanced EI MS source allow to reach sub-ppt sensitivity.

Resources

[SampleQ Web Page](#)

Highlights

- Sub-ppt sensitivity
- Compliant with the most stringent analytical requirements of current European regulations on water testing



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance


Micro-SPE clean-up

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

Instrument set-up

2x Automatic Tool Change Stations

Each station supports docking and exchange of up to three liquid tools. This workflow requires 50 μ L, 100 μ L, 250 μ L, 1 mL, 10 mL syringes



Resources

[Automated Workflows Brochure](#)

[Automated Workflow Solutions Web Page](#)

[TriPlus RSH SMART Web Page](#)

Highlights

- Extended x-rail required
- Automatic six tools changer
- On-line injection into the GC-MS/MS, with 24/7 operations

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up


LLE for Hydrocarbon Index in water

Automated workflow


A robust GC configuration with PTV injector and FID detector is used for automated in-vial extraction for the determination of Hydrocarbon Index in water samples, followed by Large Volume Injection (LVI) for sensitivity in the low ppb levels.

Automation ensures high precision (RSD < 3%), limited water sample volume (10 mL), and very low solvent consumption (2 mL/sample). The clean up with Florisil is an optional step which can be done for positive samples only.

Extraction process



Clean-up process



Resources

[Presentation: Automated In-Vial Extraction of Surface Waters for the Analysis of Mineral Oil by GC-FID](#)

[SampleQ Web Page](#)

[High-throughput mineral oil determination in water AN001289](#)

Highlights

- Fast method with Prep Ahead function
- Cycle time 21 min for 68 samples/24h
- Chromeleon CDS for instrument control, data acquisition, and reporting



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples


LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Automated LLE for Hydrocarbon Index

Instrument set-up



Resources

[Automated Workflows Brochure](#)

[Automated Workflow Solutions Web Page](#)

[TriPlus RSH SMART Web Page](#)

Highlights

- Extended x-rail required
- On-line injection into the GC-MS/MS
- 24/7 operations



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples


LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

LLE of Nitrosamines in Metformin drug substance

Nitrosamines are considered a matter of concern as mutagenic carcinogens or probable carcinogens. Since 2018, the presence of nitrosamine impurities has been highlighted by the Food and Drug Administration (FDA) within several widely employed active principles such as angiotensin receptor blockers commonly known as 'sartans' used in the treatment of hypertension and metformin, which is employed to treat diabetes. This has sometimes led to these drugs being recalled.




Nitrosamine impurities in pharmaceutical substances typically originate from the reaction between a secondary or tertiary amine present as an unintentional contaminant of raw materials, reagents, and solvents with nitrous acid, generated from nitrites through acid catalysis during the production process.

For LC-MS nitrosamine analysis, sample preparation involves a dissolution/suspension step with an aqueous/methanolic solution, followed by dilution and injection.

In the case of GC-MS, a liquid-liquid extraction step is also carried out to make the sample amenable to GC analysis.

Automation of the extraction procedures reduces the sample preparation time while improving data repeatability.



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water


Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Automated workflow



Resources

[Webinar: Confidence in Process: A Fully Automated Solution for Nitrosamine Impurity Analysis Applicable to LC-MS and GC-MS](#)

[Application Brief AB000390](#)

[Analyte Guru Blog](#)

Highlights

- Centrifugation is optional but recommended
- On-line injection is optional. The system can be used as a bench station for off-line sample preparation
- This PrepCycle can be reproduced with the SWE to modify or create additional steps



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

LLE for organic contaminants (SVOC) in water

Dispersive micro-LLE for organic contaminants (SVOC) in water samples

LLE for Hydrocarbon Index in water

LLE of Nitrosamines in Metformin drug substance

Micro-SPE clean-up

Automated LLE of Nitrosamines in Metformin drug substance

Instrument set-up

Automatic Tool Change Station

it supports docking and exchange of up to three liquid tools. This solution requires two liquid tools with a 1,000 uL syringe for water and solvent addition and a liquid tool with a 10 uL syringe for injection

Vortex Mixer

Uses a stirring step to allow for drug substance dissolution in water and to facilitate analyte partitioning during extraction

Tray Holder

Two holder slots are typically used for VT54 trays, holding up to 54 vials each and used for sample and extracts respectively. A cooled drawer can also be used

Large Wash Station


Used for syringe washing or solvent and solution storage. In this workflow, position 1 is filled with methanol and used for washing

Solvent Station

Used for 3 × 100 mL solvent bottles. Positions 1 and 2 are used for water and organic solvent

Centrifuge

Supports centrifugation of 2, 10 or 20 mL vials. The centrifugation step facilitates phase separation after solvent extraction



Resources

[Automated Workflows Brochure](#)

[TriPlus RSH SMART Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Fits a regular x-rail
- Bench working station or on-line configuration



Table of contents

The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

QuEChERS extract μ SPE clean-up for pesticide analysis

Automated μ SPE clean-up of QuEChERS extracts


The QuEChERS (Quick, Easy, Cheap, Effective, Rugged and Safe) extraction and clean-up procedure was first developed in 2003 to simplify pesticide extraction from fruits and vegetables. Today, QuEChERS or QuEChERS-like workflows have been adopted by laboratories worldwide on a wide variety of compounds and sample matrices. Depending on target analytes, processed samples can be analyzed by means of GC-MS, HPLC-MS, or both.

Food extracts require a clean up step usually performed with a solid-phase extraction (SPE) step. SPE involves partitioning between a liquid (sample matrix or solvent with analytes) and a solid sorbent phase. In the

QuEChERS procedure, clean-up is carried out manually by dispersive solid-phase extraction (d-SPE): the sorbent is introduced directly into the sample, the suspension is then vigorously shaken and centrifuged, and an aliquot of the supernatant is finally analyzed.

In micro-SPE (μ SPE), the conventional SPE cartridge is replaced by a miniaturized cartridge containing 45 mg of sorbent for GC analyses, and 30 mg for LC analyses. The μ SPE clean-up procedure is fully automated through a dedicated tool of the TriPlus RSH or RSH SMART autosampler.

The autosampler syringe works as a LC pump. Low flow rates of approximately 2 μ L/s in the load and elution steps are used for sharp analyte/matrix separation.



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

QuEChERS extract μ SPE clean-up for pesticide analysis

Automated μ SPE clean-up of QuEChERS extracts

Automated workflow

Cartridge conditioning




The conditioning of μ SPE cartridges is carried out to wet and settle the bed, activate the packing materials, and remove any residual process materials. This step is optional: It is generally carried out using acetonitrile, sometimes supplemented with acid and/or buffer solutions.

Cartridge loading and sample clean-up



The needle penetrates the septum and creates a seal so that the sample is forced through the sorbent bed by positive pressure when the plunger is depressed. The sample passes through the cartridge and is collected into a vial.

Cartridge elution



An additional cartridge elution step with solvent can be added to improve the recovery (optional)

Analyte protectant and IS addition



If required, analyte protectant and internal standard can be added to the cleaned-up sample. Analyte protectants are used in GC-MS analysis to stabilize response and maximize recovery. IS addition is useful to normalize analyte response.

Mixing



Sample mixing can be carried out by means of repeated aspiration and dispensing cycles.

Injection



Online configuration allows the processed sample to be injected immediately after clean up (optional).

Resources

[Webinar: Automated Online \$\mu\$ SPE Cartridge Clean-Up of QuEChERS Extracts Before LC-MS/MS and GC-MS/MS Analysis of Pesticides in Foods](#)

[Thermo Scientific AN 65906](#)

[Thermo Scientific AN 65684](#)

[LCGC Article](#)

[E. Hakme, M. Poulsen, J. of Chrom. A, Vol 1652 \(2021\)](#)

Highlights

- Dedicated cartridges composition for GC-MS analyses
- Improved data repeatability
- No need for re-concentration step
- Avoid possible degradation or side reactions with on-line injection



The role of sample preparation in gas chromatography

TriPlus RSH robotic sample handling

Sampling Workflow Editor software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction workflows

Micro-SPE clean-up

QuEChERS extract μ SPE clean-up for pesticide analysis

Automated μ SPE clean-up of QuEChERS extracts

Instrument set-up

Automatic Tool Change Station


Supports docking and exchange of up to three liquid tools. This solution requires a μ SPE liquid tool with needle guide for μ SPE cartridges (1000 μ L syringe), a 25 μ L syringe for internal standard, and analyte protectant addition and a 10 μ L syringe for injection

Tray Holders

House up to 3 different sample trays each. The three tray holder slots are used for sample storage, μ SPE cartridge elution and conditioning. An additional tray holder can be added, increasing capacity to 108 samples

Fast Wash Module

Provides sufficient wash solvent to clean the large volume sample preparation syringes. Wash 1 inlet is connected to a reservoir with MeOH/MeCN/H₂O (1:1:1) and Wash 2 is connected to a reservoir with Acetonitrile



Solvent Station

Holds 3 \times 100 mL solvent bottles. Positions 1 and 2 are used for conditioning and elution solvents

Standard Wash Station

Holds up to 4 \times 10 mL solvent vials and 1 \times 10 mL waste vial. Positions 1 and 2 are used for internal standard and analyte protectant, respectively. Positions 3 and 4 can be used for additional solvents

Resources

[Automated Workflows Brochure](#)

[Automated \$\mu\$ SPE Video](#)

[Automated Workflow Solutions Web Page](#)

[Sampling Workflow Editor Tutorial](#)

Highlights

- Fits a regular x-rail
- Overlapping of the clean-up with previous sample analysis (for on-line configuration)
- On-line injection or bench station for off-line sample preparation
- Suitable for cleaning-up samples for LC analysis

The role of sample preparation
in gas chromatography

TriPlus RSH robotic sample
handling

Sampling Workflow Editor
software

Calibration workflows

Derivatization workflows

Liquid/liquid extraction
workflows

Micro-SPE clean-up

 Learn more at thermofisher.com/triplusrsh

For Research Use Only. Not for use in diagnostic procedures. © 2022 Thermo Fisher Scientific Inc. All rights reserved. SampleQ is a registered trademark of Interscience. All trademarks are the property of Thermo Fisher Scientific and its subsidiaries unless otherwise specified. This information is presented as an example of the capabilities of Thermo Fisher Scientific products. It is not intended to encourage use of these products in any manners that might infringe the intellectual property rights of others. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representatives for details. **EB000396-na-en 1222S**